



Bracelet Bending Technique

Tools & Supplies:

- ImpressArt Bracelet Bending Bar
- ImpressArt Bracelet Stamping Blanks
- *Optional:* ImpressArt Bracelet Bending Pliers

After stamping is completed, use the Bracelet Bending Bar to bend the bracelet blank into a cuff shape.



1.



Place one end of blank into the channel with the stamped side facing up. Firmly place your thumb against the end of the bracelet to secure it in place.

2.



Using the palm of your hand, bend the bracelet half way.

IMPORTANT: *Make sure not to over bend.*



3.



Remove, place straight end into channel, and repeat to finish shaping the bracelet.

Optional:

The Bracelet Bending Bar creates a classic cuff shape with a flat top. To achieve a perfectly round cuff, continue with the Bracelet Bending Pliers.

1.



Match curvature of the nylon jaws to the curvature of the cuff.

2.



Starting in the center of the cuff, squeeze pliers to begin forming.

3.



Continue to squeeze and release pliers towards each end until cuff is perfectly round.